



## air<sup>3</sup> care and maintenance instructions

ecofinishes® air<sup>3</sup> floors are very easy to maintain. Simply use a wood cleaner and a specialty terry cloth flooring mop, which is available from most flooring retailers.

### step 1

Vacuum or sweep your floor to remove any particles that could scratch your floor.

### warning!

Vacuums with a beater bar or power rotary brush head can damage a wood floor and should never be used.

### step 2

Apply the specialty wood cleaner directly to the terry cloth flooring mop, not to the floor!

### step 3

Use a back and forth motion with the mop. When the terry cloth cover becomes soiled, simply replace it with a clean one. Cleaning the floor with a soiled cover could cause streaking. The covers are reusable so simply throw the cover in the wash and dry it as you would any towel.

### tips & warnings

- Vacuum or sweep regularly.
- Remove spills promptly using a wood cleaner and a clean white cloth.
- Use felt protectors under heavy pieces of furniture and chairs.
- Use protective mats at all exterior entrances.
- Spiked heels should not be worn on hardwood floors and shoes in need of repair can damage your floor.
- Never wet or damp mop your wood floors. Water can damage them.
- Never use oil soaps, wax or other household products to clean your floor.
- Wood is a natural product that is affected by the sun. Expect that over time the sun's UV rays can change the

color of your floors.

- Keep animal nails trimmed.
- Protect your floor when using a dolly for moving furniture or appliances.
- Never slide or roll heavy furniture or appliances across the floor.
- If your floor becomes scratched or dull, repairs can often be made using repair accessories.